

MIRAGE CX

TYPE II



The **Mirage CX** ambulance is a proven Demers Type II ambulance with a unique aerodynamic roof design available on both Ford diesel and Ford gasoline chassis. Fully tested, certified, and in service around the world, the CX delivers on reliability and durability, and is a cost-effective EMS vehicle.

CHASSIS

Available on Ford E-350 Van 2010

DIESEL :

- > Engine: 6.0 liter Diesel V8 Power Stroke
- > Wheelbase: 138 in. (350 cm)
- > GVWR: up to 9,500 lbs (4,309 kg)
(Gross Vehicle Weight Rating)

GASOLINE:

- > Engine: 6.8 liter EFI V10 Gasoline
- > Wheelbase: 138 in. (350 cm)
- > GVWR: up to 9,500 lbs (4,309Kg)
(Gross Vehicle Weight Rating)





2



3



4

FEATURES

- > Aerodynamic roof design with incorporated halogen warning lights for greater durability and longevity, increased visibility for improved safety and fuel cost savings of up to 12% (LED optional)
 - > 64" (163 cm) interior headroom
 - > Cabinetry construction of lightweight materials combining Demers- exclusive "Interlock" rounded aluminum extrusion with modular fiber-glass cabinet inserts, shatterproof Lexan doors and aluminum panels for a safer work environment, long-lasting interior, increased resale value and better fuel economy 1
 - > Excellent payload capacity of over 1900 lbs (861 kg)
 - > Sub-floor plywood with lap joint construction to eliminate floor cracking. Strong, durable aluminum extrusions with permanent rolled edge provide the foundation for mounting the cabinetry and squad bench, while supporting the rolled edge flooring material. Ultra-strong construction for durability, increased safety and minimum bacterial infiltration
-
- > Standard Demers Management Electronic System **Multiplex (DEMS)** offers full operational flexibility to easily customize the vehicle's electronic functions to specific needs, controls heat & AC systems separately for maximum efficiency and for easier diagnostics and service
 - > Exclusive Heads-Up Console (HUC) on dashboard provides easy access to ambulance features while letting drivers keep their eyes on the road for increased safety
 - > Extra space behind driver and passenger seat for greater seat recline and comfort
 - > Electric door locks on all doors
 - > 2 batteries with isolator for chassis & module power
-
- > Ergonomic module design allows for the transport of a 2nd patient on a backboard 2 (option)
 - > Rear-facing, tested and certified full-size captain's chair with 3-point seat belt 3
 - > Ergonomic vertical rear O2 stowage
 - > Portable O2 stowage on side door 4
 - > Seamless interior for easy maintenance, durability and maximum safety

Plus multiple options to build the Mirage CX your way.

To know more about the Mirage CX ambulance, find all the details at www.demers-ambulances.com

Or, please contact us directly at **1-800-363-7591** to speak to one of our sales representatives or to be redirected to your local dealer.

THE DEMERS DIFFERENCE

Demers' 50 years of experience and customer feedback have led to continual upgrades, improvements and innovations, driven by the philosophy that every single detail contributes to a superior vehicle. Details that today make Demers ambulances some of the safest on the road, and that deliver significant and tangible added value in terms of safety, ingenious design and ergonomics, along with low operating costs. Detail by detail, Demers has been raising the bar, making ambulances which exceed the sum of their parts and are standouts in the industry. Ambulances engineered to keep your people safe. So they can keep on saving lives.

