

MYSTERE MX 170 S

TYPE III



The **Mystere MX 170 S** is our state of the art, full size Type III ambulance, offering a roomy interior for extensive medical equipment and an optimal ergonomic work environment for EMS specialists. Tested to global standards, this ambulance is built with unique features such as full length, all-aluminum extruded door construction for maximum storage access without compromising structural integrity. Equipped with our Industry-leading mobility track seat, the MX 170S is the leader in its category.

CHASSIS

Available on Ford E450 Super Duty Cutaway Van 2010 chassis

- > Engine: 6.8 liter EFI V10 gasoline engine
- > Wheelbase: 158" (401 cm)
- > GVWR: Up to 14,500 lbs (6,577 kg) (Gross Vehicle Weight Rating)

Available on GM Chevrolet Express 4500 Cutaway 2010 chassis

- > Engine: VORTEC 6.0 liter V8 SFI gasoline engine including auxiliary transmission oil cooler
- > Wheelbase: 159" (404 cm)
- > GVWR: Up to 14,200 lbs (6,441 kg) (Gross Vehicle Weight Rating)



Ford is a registered trademark of Ford Motor Company, Limited. All rights reserved.
Chevrolet is a registered trademark of General Motors Company. All rights reserved.



2



3



4

FEATURES

- > Aerodynamic roof design with incorporated full LED warning lights for greater safety and fuel cost savings of up to 12%
- > 72" (183 cm) interior headroom
- > Cabinetry construction of lightweight materials combining Demers-exclusive "Interlock" rounded aluminum extrusion with modular fiberglass cabinet inserts, shatterproof Lexan doors and aluminum panels for a safer work environment, long-lasting interior and better fuel economy 1
- > 170"L x 95"W modular body (432 cm X 241 cm), an all-aluminum structure, fully welded, with single sheet side walls & roof, and ample exterior storage
- > Sub-floor plywood with lap joint construction to eliminate floor cracking. Strong, durable aluminum extrusions with permanent rolled edge provide the foundation for mounting the cabinetry and squad bench, while supporting the rolled edge flooring material. Ultra-strong construction for durability, increased safety and minimum bacterial infiltration
- > Spacious front cabin: extra 1" for seat recline (KKK + 1"), large door and window view to module and large vertical stowage
- > Best in class payload capacity: up to 3400 lbs (1,542 kg) offering additional space for medical equipment

- > Standard Demers Electronic Multiplex System (DEMS) offering full operational flexibility to easily customize the vehicle's electronic functions to specific needs. Access from large exterior door for easy access and maintenance
- > Separate Multiplex controlled heating & A/C systems for maximum efficiency and for easier diagnostics and service
- > Exclusive Heads-Up Console (HUC) on dashboard provides easy access to ambulance features while letting drivers keep their eyes on the road for increased safety 3
- > 100-watt electronic siren with dual grille-mounted speakers ideal for sound projection and inside cab comfort

- > Emergency door override system increases occupant safety in case of evacuation after an accident
- > Dual seal protection safeguards onboard environment from outside contamination. Door latch protection for long durability
- > Multiple exterior stowage compartments - one with lighting and double access, from exterior door and from module
- > Main oxygen bottle in exterior compartment with window view from module

- > Exclusive Demers "Mobility track" curbside captain's chair with 3-point seat belt 2
- > Seamless interior for easy maintenance, durability and maximum safety
- > Standard anti-slip chassis running boards
- > Enclosed portable O2 on exterior door(s)
- > Monitor /defibrillator mounting options 2
- > Front attendant captain's chair with 3-point seat belt
- > Forward facing captain's chair with 3-point seat belt on left side 4

Plus multiple options to build the Mystere MX 170 S your way.

To know more about the Mystere MX 170 S ambulance, find all the details at www.demers-ambulances.com

Or, please contact us directly at **1-800-363-7591** to speak to one of our sales representatives or to be redirected to your local dealer.

THE DEMERS DIFFERENCE

Demers' 50 years of experience and customer feedback have led to continual upgrades, improvements and innovations, driven by the philosophy that every single detail contributes to a superior vehicle. Details that today make Demers ambulances some of the safest on the road, and that deliver significant and tangible added value in terms of safety, ingenious design and ergonomics, along with low operating costs. Detail by detail, Demers has been raising the bar, making ambulances which exceed the sum of their parts and are standouts in the industry. Ambulances engineered to keep your people safe. So they can keep on saving lives.

