

MIRAGE EX SPRINTER

TYPE II



The **Mirage EX Sprinter** stands alone in its Type II category, thanks to its unique aerodynamic front cab riser and rear spoiler perfectly engineered to match the Mercedes-Benz and Freightliner Sprinter design. It features Demers' unmatched ergonomic safety features and details that have set new standards in an industry where every detail matters.

CHASSIS

- > TYPE II Sprinter cab chassis from Mercedes-Benz and Freightliner
- > GVWR 8,550 lbs (3,878 kg)
- > Warranty: 5 years/96,000 miles engine (160,000 km) and 5 years/60,000 miles powertrain (100,000 km)
- > Adaptive ESP; first driving dynamics regulatory system taking vehicle load into account
- > Powerful new 3.0-liter V6 Turbo Diesel engine. 188 hp @ 3,800 rpm 325 lbs-ft of torque at 1,400-2,400 rpm
- > Excellent crash characteristics: high stress-resistant system of beams and high-strength passenger safety cell



Mercedes-Benz



Mercedes-Benz is a registered trademark of Daimler AG. All rights reserved.
Freightliner is a registered trademark of Daimler Trucks North America LLC,
a Daimler AG Company. All rights reserved.





3



4



5

FEATURES

- > Aerodynamic roof design with incorporated LED warning lights for greater safety and fuel cost savings of up to 12%
 - > 75" (191 cm) High-roof; paramedics can stand and walk easily in the ambulance (front & back)
 - > Cabinetry construction of lightweight materials combining Demers-exclusive "Interlock" rounded aluminum extrusion with modular fiberglass cabinet inserts, shatterproof Lexan doors and aluminum panels for a safer work environment, long-lasting interior and better fuel economy 1
 - > Sub-floor plywood with lap joint construction to eliminate floor cracking. Strong, durable aluminum extrusions with permanent rolled edge provide the foundation for mounting the cabinetry and squad bench, while supporting the rolled edge flooring material. Ultra-strong construction for durability, increased safety and minimum bacterial infiltration
 - > Best in class payload capacity: over 2,000 lbs (948 kg) offering additional space for medical equipment
- > Standard Demers Management Electronic System Multiplex (DEMS) offering full operational flexibility to easily customize the vehicle's electronic functions to specific needs 2
 - > Multiplex controlled ESPAR efficiency fuel fired heating system for patient compartment delivers 100% of its heat in 2 minutes for maximum comfort and efficient air circulation. Heating & A/C systems remain separate for maximum efficiency and for easier diagnostics and service
 - > Exclusive Heads-Up Console (HUC) on dashboard provides easy access to ambulance features while letting drivers keep their eyes on the road for increased safety
 - > 100-watt electronic siren with dual grille-mounted speakers ideal for sound projection and inside cab comfort
 - > Emergency lights on the side sliding door for constant high visibility even when it's opened
- > Low Profile Option; for those with low clearance issues on the Sprinter chassis 3
 - > 7 LED interior lights; maximum lighting with very low energy consumption
 - > Ergonomic stowage location of a large wheeled/tracked stair chair; easy reach & access
 - > Rear vertical stowage space for main oxygen bottle; easy reach & access 4
 - > Electronic low pressure warning system for the main oxygen cylinder
 - > 2-place squad bench + curb side location for the cardiac monitor
 - > Vertical ergonomic stowage space for two 18" backboards and one scoop stretcher; easy reach & access
 - > Multiple additional stowage spaces; double-lock narcotics compartment; personal gear stowage module in cab; larger left wall cabinetry 5

Plus multiple options to build the Mirage EX Sprinter your way.

To know more about the Mirage EX Sprinter ambulance, find all the details at www.demers-ambulances.com

Or, please contact us directly at **1-800-363-7591** to speak to one of our sales representatives or to be redirected to your local dealer.

THE DEMERS DIFFERENCE

Demers' 50 years of experience and customer feedback have led to continual upgrades, improvements and innovations, driven by the philosophy that every single detail contributes to a superior vehicle. Details that today make Demers ambulances some of the safest on the road, and that deliver significant and tangible added value in terms of safety, ingenious design and ergonomics, along with low operating costs. Detail by detail, Demers has been raising the bar, making ambulances which exceed the sum of their parts and are standouts in the industry. Ambulances engineered to keep your people safe. So they can keep on saving lives.

